

Attention:Do not tighten the screws until you have complete setup assembly. (3)x4(2) (4) (5) M5*50=12M4*12=4 (5)x2(6)(1) 56*40cm (2)(9) (8)(6) (5)