































ASSEMBLY INSTRUCTIONS

NO.: DK-240582


A  X1	B  X1	C  X1
D  X1	E  X1	F  X1
G  X1	H  X1	I  X1
J  X2	K  X4	L  X4
M  M6*16mm X12	N  M6*25mm X16	O  M6*55mm X8
P  X8	Q  X8	R  M6 X1




STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9




STEP 10




STEP 11




STEP 12




STEP 13




STEP 14




STEP 15



STEP 16



STEP 17



STEP 18

